

Panasonic 624 System

Set Time At Phone Ext. 101

1. Set switch on top side to program
2. Press * # 1616
3. Press 000
4. Press (speaker phone)
5. Press FWD/DND until time is flashing FWD cycles through date 1st – press current time hour first then “FWD” over to minutes enter minutes
6. Press Auto Dial/Store then move switch on top side back to “set”