

Security Cheat Sheet

1st make sure that all doors and windows are closed. To do this press the left or right arrow. The display should change to "Enter Code To Arm System". If not, it will show the name of the window or door that is open. Press the right arrow again to see any additional zones that might be open.

Arming System: Enter your 4 digit code. The display will change to "(0) to arm Main House", press the * key to select this. The display will now change to " Exit Delay In Progress" and will be counting down and beeping once per second. Exit the premises.

Disarming System: Enter your 4 digit code; the display will change to "System Disarmed No Alarm in Memory"

Quick Arm: Press the * key then the 0 key, the system should start counting down the exit delay.

System Trouble: If the yellow trouble light comes on the keypad will start beeping once every 10 seconds. To stop the beeping, press *2. This also show exactly what the trouble is.

Activating Door Chime: *Keypad Command: [*][4]*

When the door chime feature is enabled, the keypad will emit five quickbeeps when a zone is opened or closed. The keypad will only beep for zones which have the door chime zone attribute enabled. Often this feature is applied to entry doors so that you are notified when someone enters or exits the premises. To enable door chime, enter [*] [4] at any keypad.

Viewing Trouble Conditions: The alarm control panel continuously monitors a number of possible trouble conditions. If one of these conditions occurs, the keypad Trouble light will turn on and a beeping sound will be heard every 10 seconds. Press the [#] key to silence the keypad. The Trouble light will stay on until the trouble is cleared.

To view which trouble conditions are present:

1. Enter [*] [2] at any keypad.

2. Use the arrow (< >) keys to scroll through the list of trouble conditions:

If AC Trouble is present, the system has lost its power. This trouble may be due to a power outage and should be cleared once the power is restored.

If the power on the premises is running normally and the trouble condition persists, call your installer for service. If TLM Trouble is present, there is a problem with the telephone line. If the telephones on the premises are running normally and the trouble condition persists, call your installer for service. Any other trouble condition will require the assistance of your installer. As soon as a trouble condition occurs, call your installer to have the problem corrected as soon as possible.

What to Do If An Alarm Sounds: Fire Alarm: If your system has been installed with fire detectors, a fire alarm will be indicated by a pulsing siren. If you hear a fire alarm, follow your emergency evacuation plan immediately (see Section 6.5 "Fire Escape Planning").

Intrusion Alarm: An intrusion alarm will be indicated by a continuous bell or siren. You can silence an intrusion alarm by entering a valid access code. If the alarm was unintentional, call local authorities immediately to avoid an unnecessary response. You can determine the source of the alarm by entering the alarm memory mode. Once the source of the alarm has been corrected, the panel can be restored to its original armed state.